

## Product Data Sheet

### NewPro-Aluminum Rim Cleaner

#### Product Description

NewPro-Aluminum Rim Cleaner is an environmentally safe cleaner for the thorough removal of dirt, grime, and deposits on aluminum rims.

#### Range of Application

NewPro-Aluminum Rim Cleaner can be applied and used as an environmentally safe cleaner for the thorough removal of brake dust, grease, oil and other deposits, which cling to aluminum rims.

To supplement this cleaner, NewPro offers a nano-protective sealant for aluminum rims. In the first 6 months after NewPro-Nano Alloy-Rim-Fit has been applied to the surface of the alloy rims, dirt and grime can be easily rinsed off with water jet/spray without the need for any further cleaning or after treatment.

Further information about NewPro-Nano Alloy-Rim-Fit can be obtained by request or found on our Internet Site: [www.G-Pro.com](http://www.G-Pro.com)

#### Product Characteristics

NewPro-Aluminum Rim Cleaner exhibits the following characteristics:

- Easy-to-Apply
- Environmentally Safe
- High Cleaning Effect
- High Productivity
- Odorless
- Short Time to Take Effect.

#### Application Instructions

Mixing Instructions:

NewPro-Aluminum Rim Cleaner is not to be mixed or diluted. The cleaning properties will be negatively affected by the mixture or addition of foreign substances.

Application:

Spray NewPro-Aluminum Rim Cleaner to the dirt or soiled area and wait up to 1 minute for the cleaner to take effect. After the the product takes effect, rub off the dissolved dirt and grime particles using a moistened towel or sponge and rinse off with sufficient clean water.

Refer to further instructions under the heading: Required Conditions for Use/ Application.

As a supplemental product to this cleaner, NewPro offers a Nano Protective Sealant for aluminum rims.

In the first 6 months after NewPro-Nano Alloy-Rim-Fit has been applied to the surface of the alloy rims, dirt and grime can be easily rinsed off with water jet/spray or, as a general rule, without the need for any further cleaning or after treatment.

Further information about NewPro-Nano Alloy-Rim-Fit can be obtained by request or found on our Internet Website: [www.G-Pro.com](http://www.G-Pro.com)

Machine Application:

NewPro-Aluminum Rim Cleaner can be applied using a standard or common Airless/Spray device.

## Application Instructions

Notice:

Do not allow NewPro-Aluminum Rim Cleaner to dry onto the cleaned surfaces.

Use:

- Dependent upon the degree of dirt, grime and soiling. An exact amount of material needed can only be determined by a sample cleaning of the surface of the object.

## Required Conditions for Use/Application

Application of the product and drying can be applied with a surface and the air temperature between min. +5° Celsius and max. +30° Celsius.

The product must not be applied at temperatures over +25° Celsius under direct sunlight – the product must not dry onto the surface.

Time to Take Effect:

- Approximately 1 minute (at approximately +20° Celsius). A longer time to take effect is not recommended.

Notice:

Do not allow NewPro-Aluminum Rim Cleaner to dry onto the cleaned surfaces.

Cleaning of Tools:

- Clean with clear water directly after use. In freshly used condition, clean with water.

## Delivered Form

Units Per Package:

- Units Per Package = 1 liter bottle.

Color:

- Colorless.

## Further Instructions

Transport:

- Unlabeled and non-hazardous.

Storage:

- Cool, frost-protected, in original closed package, product has a shelf life of approximately 1 year.

## Work Hygiene

Before breaks and at the end working with the product, wash hands thoroughly.

Do not eat, drink or smoke during use. Avoid eye and skin contact with the product.

If necessary use proper protective clothing while working with the product.

For further instruction, please refer to the product data safety sheets for the product.

## Safety Precautions

Keep away from children. Keep containers sealed tightly closed. In the event of eye contact, immediately flush eyes out with lots of clean water. In the event of skin contact, wash skin thoroughly with water and soap. If necessary seek medical advice. Do not smoke during application and use. If swallowed seek immediate medical advice and show the packaging or product label to the treating physician.

For further safety precautions, please refer to the safety product sheets of the product.

## Safety and Protective Measures

The general protective measures for water-soluble materials are to be taken.

The technical advice regarding the use and application of our products is the result of extensive research and development as well as many years of experience, according to the best of our knowledge. The different kinds of requirements of an object, under varying conditions, make it necessary for the user to check the suitability for the intended purpose. We reserve the right to effectuate changes, which serve to affect the technical advance or improvement of our product.

For further instruction, please refer to the product data safety sheets for the product.

**This product is intended for commercial use only!**